

1 (January 5, 2004)

2 **Transverse Joints**

3 The full depth end of each lane of planing shall be squared off to form a uniform  
4 transverse joint. The Contractor shall construct and maintain a temporary HMA  
5 wedge in accordance with Section 5-04.3(11) across the entire width of the  
6 transverse edge when traffic is allowed on the planed surface prior to paving. The  
7 wedge shall be constructed before opening the lane to traffic. The Contractor shall  
8 remove the wedge immediately prior to paving.